

Setting up the U-Phase Wire Marker display panel.

Holding panel as shown below, fold back the long tab "A". Continue by folding back tabs "B" and "C".



Position folded tab "A" on the front top edge of the display box and insert the lower half of folded tabs "C" into the slotted area just beneath the top of display.

